



**COMPONENTS FOR GEAR STARTERS**

**Bosch**



IKA-No.	Original	References	Unit-Nos.
4 2214 0	Bosch	1 005 821 333	Gear 1 006 200 088,096,099-101,117, 118,122,126,143,166 0 001 109 014,015,018,019,025,026,028, 030,031,033,036,041,042,048, 052,055,061,062,068,200, 202-204,252,253,264,267-270, 336,337,340,341,364 0 001 110 112 0 001 124 001-008,011-015,022-025 0 001 125 001-013,016-019,021,022,025, 031,032,035,036,039,040,042, 043,046-049,051,052,055-060, 501-504,507,508,511-514, 517,518,602,605,606,617,618 F 002 G20 292,524,618,622,658,672

**reference list:**

manufacturer	references
Bosch	1 005 821 333
Cargo	139143