



**COMPONENTS FOR GEAR STARTERS**

**BOSCH**

<b>IKA-No.</b>	<b>Original</b>	<b>References</b>	<b>Unit-Nos.</b>
4 2256 0	Bosch	Outer Gear	0 001 107 401-405,408-411,417,417, 421,422,427,428,430,446, 447,490,491,499-502 0 001 108 400-402,405,406,408,412, 430,431 0 399 708 303,301 F 004 A94 000,001,004,410,418